

CALLIERT

INSTALLATION MANUAL

07-18 JEEP WRANGLER JK Full-Length ROOF RACK



CAUTION BEFORE INSTALLING

Before installation - Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
E-mail: tech@calliert4x4.com

CALLIERT is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.


Proper installation of this kit requires knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle.



- Always wear eye protection when operating power tools. •

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information:

- Name of purchase location
- Bar Code on side of box


INSTALLATION MANUAL



a.	 M8x35mm Button Head Hex Socket Bolt	<input type="checkbox"/> ×8	e.	 M8x20mm Button Head Hex Socket Bolt	<input type="checkbox"/> ×8	i.	 M8 Washer	<input type="checkbox"/> ×26
b.	 M6x12mm RoundHead Hex Socket Bolt	<input type="checkbox"/> ×12	f.	 M8 x 40mm Cylindrical Head Hex Socket Bolt	<input type="checkbox"/> ×8	j.	 58mmx18mmx4.5mm Washer	<input type="checkbox"/> ×6
c.	 M6x20mm RoundHead Hex Socket Bolt	<input type="checkbox"/> ×12	g.	 20mmx13mmx5mm Square Nut	<input type="checkbox"/> ×12	k.	 55mmx18mmx3mm Slide-in Double TNut	<input type="checkbox"/> ×4
d.	 M6 Washer	<input type="checkbox"/> ×8	h.	 M8 Hex Flange Nut	<input type="checkbox"/> ×20	l.	 46mmx51mmx6mm Nuts Bracket	<input type="checkbox"/> ×2

CALLIERT


INSTALLATION MANUAL



Prepare the required parts (④*1, ⑤*1, ⑥*1, c*4, d*4).
As shown in the diagram, connect ④ and ⑤ using ⑥, c, and d.
Note: The operation steps are identical for both sides,
but left/right orientation must be strictly differentiated.

CALLIERT

INSTALLATION MANUAL



Prepare the required part (②*1). As shown in the diagram, Remove the pre-installed screws from ②. Connect the pre-assembled ⑤ to ②. Secure the connection using the removed screws.

/// **CALLIERT**

INSTALLATION MANUAL



Prepare the required parts (g*12).
As shown in the diagram,
slide g into the slots of the pre-connected ④ and ⑤ assembly.



CALLIERT

INSTALLATION MANUAL



Prepare the required part (①*1).
As shown in the diagram, Remove the pre-installed screws from ①
Connect the pre-assembled ④ to ①
Secure the connection using the removed screws.

CALLIERT

INSTALLATION MANUAL




Prepare the required parts (③*6, b*12).
As shown in the diagram, Adjust g to optimal positioning
Secure ③ and the main body using b and g
Note: ③ has no fixed mounting position (freely adjustable),
ensure positional clearance from bracket holes during adjustment.



CALLIERT

INSTALLATION MANUAL



Prepare the required parts (⑧*2, ⑨*2, ⑪*2, a*4, e*8, h*12, i*12, j*2, l*2).

As shown in the diagram, Connect ⑧ and ⑨ using e, h, i
Connect l and luggage rack using a, h, i, j, Screw ⑪ to the holes on l.



INSTALLATION MANUAL



Prepare the required parts (⑩*2).

As shown in the diagram, Remove the original screws from tailgate
Insert ⑩ between tailgate and vehicle body, Secure using removed original screws.



CALLIERT

INSTALLATION MANUAL



Prepare the required parts (⑦*2, ⑧*2).

As shown in the diagram, loosen the pre-installed screws at the bases of ⑦ and ⑧, then slide them into the vehicle roof rain channel.

Note: ⑦ stays at rain channel front, ⑧ stays at rain channel rear.

INSTALLATION MANUAL



Prepare the required parts (a*4, f*8, h*4, i*12, j*4, k*4).

As shown in the diagram,

Lift luggage rack to vehicle roof, slide bracket to align with luggage rack holes, secure ⑨ and luggage rack using a, h, i, secure ⑦ and luggage rack using f, i, j, k, secure ⑩ and luggage rack using f, i, j, k.

CALLIERT

INSTALLATION MANUAL



INSTALLATION COMPLETED

 **CALLIERT**